



200 ppm



400 ppm



600 ppm



1000 ppm



1500 ppm

## HR QAC QR TEST STRIPS

### CODE 2951HR

1. Immerse pad in solution and remove immediately.
2. Hold strip level for 5 seconds. Shake off excess water from pad. Compare pad to color chart above.

- NOTE:**
- Sample must be at room temperature (above 75°).
  - If testing Hyamine 1622, change dip time to 45 seconds in Step 1.
  - Keep out of sunlight.
  - Keep vial closed when not in use.



PO BOX 329 • CHESTERTOWN • MARYLAND • 21620  
410-778-3100

Lot# 2269  
Exp. 7/14

